



IF FIRE HYDRANT IS AT END OF LINE
 USE TEE WITH M.J. TO PVC RESTRAINER
 ALSO PLACE CONCRETE BLOCKING BEHIND
 PLUGGED TEE.

PLAN
FIRE HYDRANT

NOTE:

1. USE D.I. PIPE WITH RETAINER GLANDS, FOSTER ADAPTERS, OR ANCHOR COUPLINGS TO SECURE ALL FITTINGS
2. FIRE HYDRANTS SHALL BE EITHER:
 - A: AMERICAN DARLING B-84-B
 - B: MUELLER CENTURION
 - C: U.S. PIPE METROPOLITAN 250